



Empowering your business, one transaction at a time.

Innovative payment solutions delivered with a personal touch.

Accept payment in-person or online with our innovative terminal solutions. Whether you need a stationary, wireless, mobile, or virtual terminal, a payment gateway, or software integration, ECS is the right choice for you.

Diverse Solutions for every scenario.



Lending

Lending your way to provide you with the instant capital you need.



ACH

Completely electronic, ACH transactions are efficient and low-cost.



ATM

Connect to all major ATM networks.



Merchant Cash Advance

Access the assets your business deserves.



Banking

Access our affordable rates and award-winning merchant services team.



Credit & Debit

Diverse range of credit and debit card processing solutions.



Remote Deposit Capture

No need to go to the bank to cash payment checks.



High-Risk

We're built to handle complex merchants, regardless of your industry.

To find out more [click here](#)

ANDROID TERMINALS



These steps have been provided to assist you with your Dejavoo touch screen payment device with AURA software.

IMPORTANT: As well as the payment icons (ie Credit, Debit, EBT Food, EBT Cash and Cash), the terminal's idle prompt also displays the following icons:

★ Access to the FAVORITES menu

☰ Access to the CORE menu

☎ CALL ME feature

CHIP CREDIT SALE

1. Tap on the **CREDIT** icon on your terminal home screen.
2. Tap on the **SALE** icon.
3. Input the **SALE AMOUNT** and press **OK**.
4. Tap (contactless only) or insert chip card.
5. If prompted, confirm the sale amount by tapping **OK** or **NO**. *Conditional on the terminal's configuration.*
6. The transaction is processed. Sales receipts will print with details of the transaction.

MANUALLY ENTERED SALE

1. Tap on the **CREDIT** icon on your terminal home screen.
2. Tap on the **SALE** icon.
3. Input the **SALE AMOUNT** and press **OK**.
4. Manually input **CARD #**.
5. Follow the CNP prompts (input exp. date, ZIP code etc). *Conditional on the terminal's configuration.*
6. The transaction is processed. Sales receipts will print with details of the transaction.

DEBIT SALE

1. Tap on the **DEBIT** icon on your terminal home screen.
2. Tap on the **SALE** icon.
3. Input the **SALE AMOUNT** and press **OK**.
4. Tap (contactless only) or insert chip card.
5. If prompted, confirm the sale amount by tapping **OK** or **NO**. *Conditional on the terminal's configuration.*
6. Customer enters PIN on encrypted terminal PIN Pad or encrypted external PIN Pad and presses **OK**.
7. The transaction is processed. Sales receipts will print with details of the transaction.

VOID CREDIT TRANSACTION (Card Present)

1. Tap on the **CREDIT** icon on your terminal home screen.
2. Tap on the **VOID** icon.
3. Input the **VOID AMOUNT** and press **OK**.
4. If prompted, confirm the void amount by tapping **OK** or **NO**. *Conditional on the terminal's configuration.*
5. If prompted, input **MANAGER PASSWORD** (default password is 1234).
6. Tap (contactless only) or insert chip card.
7. Enter the void transaction # and press **OK**.
8. The transaction is processed. Void receipts will print with details of the transaction.

CREDIT CARD RETURN

1. Tap on the **CREDIT** icon on your terminal home screen.
2. Tap on the **RETURN** icon.
3. Input the **RETURN AMOUNT** and press **OK**.
4. If prompted, confirm the return amount by tapping **OK** or **NO**. *Conditional on the terminal's configuration.*
5. If prompted, input **MANAGER PASSWORD** (default password is 1234).
6. Tap (contactless only) or insert chip card.
7. The transaction is processed. Return receipts will print with details of the transaction.

VOID BY TRANSACTION # (Card NOT Present)

1. From the idle prompt, tap the ★ icon to access the **FAVORITES** menu.
2. Tap **VOID TRANSACTION**.
3. If prompted, input Manager Password (1234 default).
4. Tap **BY TRANSACTION #**.
5. Input **TRANSACTION #** to be voided and press **OK**.
6. Confirm the void transaction by tapping **SELECT**.
7. If prompted, confirm the void amount by tapping **OK** or **CANCEL**. *Conditional on the terminal's configuration.*
8. If prompted, input Manager Password (1234 default).
9. The void is processed. Void receipts will print with details of the transaction.

REPRINT RECEIPT

1. From the idle prompt, tap the ★ icon to access the **FAVORITES** menu.
2. Tap **REPRINT RECEIPT**.
3. If prompted, input Manager Password (1234 default).
4. Tap desired option (**LAST, BY TRANSACTION #** or **BY CARD NUMBER**).
5. Follow prompts and transaction receipt prints.

SETTLE DAILY BATCH

1. From the idle prompt, tap the ★ icon to access the **FAVORITES** menu.
2. Tap **SETTLE DAILY BATCH**.
3. If prompted, input Manager Password (1234 default).
4. Terminal communicates with the host.
5. Settlement Report prints.

CALL ME FEATURE (Must be Enabled)

1. From the terminal main screen tap the ☎ icon.
2. If prompted, input Manager Password (1234 default).
3. Tap **CALL ME**, under the Support Menu.
4. The terminal sends notification to the help desk and you will receive a call back from a representative with assistance.

PRINTING REPORTS

1. From the idle prompt, tap the ★ icon to access the **FAVORITES** menu.
2. Tap desired report type (**DAILY REPORT** or **SUMMARY REPORT**).
3. If prompted, input Manager Password (1234 default).
4. **REPORT** prints.

WIRELESS ICONS



Wi-Fi icon will blink when not connected. It will remain static when connected successfully.




Battery charge indicator.

TURN SERVER PROMPT ON/OFF

1. From the idle prompt, tap the ☰ icon to access the **CORE** menu.
2. Tap **APPLICATIONS**.
2. Tap **CREDIT/DEBIT/EBT**.
2. Tap **SETUP**.
3. If prompted, input Manager Password (1234 default).
4. Tap **TRANS PROMPTS**.
5. Tap **CLERKS**.
2. Tap **PROMPT**.
7. Tap to select desired option.
8. Press the ◀ key continually to return to the homescreen.

TERMINAL POWER OFF/REBOOT

1. Press the  button on the side of the terminal and hold until a menu appears on the screen, with the following options: **Power off**, **Reboot**, **Airplane mode** and **Silent mode**.
2. Select the option you desire by tapping on the screen.